

FIG. 1




FIG. 2




FIG. 3




FIG. 4A






FIG. 4B

FIG. 4








FIG. 6




SCREEN THAT APPEARS WHEN TEXT T1 "ON-THE-AIR PROGRAM GUIDE" IN FIG.5 IS SELECTED

FIG. 7




SCREEN THAT APPEARS WHEN TEXT T12 "LESSONS IN EVERYDAY ENGLISH CONVERSATION" IN FIG.6 IS SELECTED

FIG. 8




SCREEN THAT APPEARS WHEN TEXT T41 "LESSONS IN EVERYDAY
ENGLISH CONVERSATION" IN FIG.7 IS SELECTED

FIG. 9



SCREEN THAT APPEARS WHEN TEXT T42 "INSTRUCTORS"
IN FIG. 7 IS SELECTED

FIG. 10



SCREEN THAT APPEARS WHEN TEXT T43 "THE TEXTBOOK"
IN FIG. 7 IS SELECTED

FIG. 11






FIG. 12




SCREEN THAT APPEARS WHEN TEXT T2 "BROADCAST CHANNEL GUIDE" IN FIG. 5 IS SELECTED

FIG. 13



SCREEN THAT APPEARS WHEN TEXT T61 "NNN" IN FIG. 12 IS
SELECTED

FIG. 14



SCREEN THAT APPEARS WHEN TEXT T71 "GENRES" IN FIG.13 IS SELECTED

FIG. 15






FIG. 16



SCREEN THAT APPEARS WHEN TEXT T91 "RERUNS" IN FIG. 15 IS SELECTED

FIG. 17



SCREEN THAT APPEARS WHEN TEXT T101 "SET YOUR VCR TO
VIDEOTAPE" IN FIG.16 IS SELECTED